

**FLOW OF WATER IN OPEN
CHANNELS, PIPES, SEWERS,
CONDUITS, &C.: WITH TABLES
BASED ON THE FOMULÆ OF
D'ARCY, KUTTER AND BAZIN**

Published @ 2017 Trieste Publishing Pty Ltd

ISBN 9780649477012

Flow of Water in Open Channels, Pipes, Sewers, Conduits, &C.: With Tables Based on the
Fomulæ of D'arcy, Kutter and Bazin by P. J. Flynn

Except for use in any review, the reproduction or utilisation of this work in whole or in part in any form by any electronic, mechanical or other means, now known or hereafter invented, including xerography, photocopying and recording, or in any information storage or retrieval system, is forbidden without the permission of the publisher, Trieste Publishing Pty Ltd, PO Box 1576 Collingwood, Victoria 3066 Australia.

All rights reserved.

Edited by Trieste Publishing Pty Ltd.
Cover @ 2017

This book is sold subject to the condition that it shall not, by way of trade or otherwise, be lent, re-sold, hired out, or otherwise circulated without the publisher's prior consent in any form or binding or cover other than that in which it is published and without a similar condition including this condition being imposed on the subsequent purchaser.

www.triestepublishing.com

P. J. FLYNN

**FLOW OF WATER IN OPEN
CHANNELS, PIPES, SEWERS,
CONDUITS, &C.: WITH TABLES
BASED ON THE FORMULÆ OF
D'ARCY, KUTTER AND BAZIN**

FLOW OF WATER
IN
OPEN CHANNELS

PIPES, SEWERS, CONDUITS, &C.,

WITH TABLES,

BASED ON THE

FORMULÆ OF D'ARCY, KUTTER AND BAZIN.

BY

P. J. FLYNN, CIVIL ENGINEER,

*Author of "Hydraulic Tables, Based on Kutter's
Formula, for Circular and Egg-Shaped Sewers."*



NEW YORK:

D. VAN NOSTRAND COMPANY,

23 MURRAY AND 27 WARREN STS.

1911

PREFACE.

THE formulæ of D'Arcy, Kutter and Bazin are gradually, but surely, being adopted instead of the old formulæ of D'Aubisson, De Prony, Downing, &c.

The former formulæ, however, though admitted to be more accurate, are also, as a rule, more complicated in form, and more troublesome and tedious in their application, than most of the old formulæ in use. In these days, when numerous works on Sewerage, Water Supply, Irrigation, &c., are being constructed in this country, and in fact all over the civilized world, hydraulic formulæ are, perhaps, in more general use by Engineers than at any former time, and therefore, any ready method which combines rapidity with accuracy in the application of the new formulæ will, very likely, tend to their more general use than at present.

It is believed that this combination of rapidity with accuracy can be gained by the proper use of the tables in this book; and Hydraulic Engineers, who make it a practice to use the formulæ of D'Arcy, Kutter and Bazin, and to whom a saving of time and tedious computation is an object, will find the tables of material help in the solution of problems relating to the flow of water in open and closed channels.

CONTENTS.

Discussion on Formulas and Tables.....	7
Explanation and Use of the Tables.....	44
Table 1, based on D'Arcy's Formula for Clean Pipes.....	57
Table 2, based on Kutter's Formula, with $n=.011$	62
Table 3, based on Kutter's Formula, with $n=.012$	67
Table 4, based on Kutter's Formula, with $n=.013$	72
Table 5, based on Bazin's Formula for open channels of the second category.....	77
Table 6, Values of \sqrt{r} for Diameters given in Tables.....	79
Table 7, Slopes.....	81
Table 8, Comparison of Coefficients (c), Kut- ter and D'Arcy.....	114
Table 9, Comparison of Coefficients, Kut- ter, D'Arcy and Fanning.....	116
Table 10, Comparison of Velocities, Kutter's Formula and Tables.....	117
Table 11, Comparison of Velocities, Kutter's Formula and Tables.....	118



FLOW OF WATER IN OPEN CHANNELS,

PIPES, SEWERS, CONDUITS, &c.

In the following formulæ let—

V = velocity in feet per second.

Q = discharge in cubic feet per second.

C = coefficient of mean velocity.

S = fall of water surface (*h*), in any distance (*l*), divided by that distance

$$= \frac{h}{l} = \text{sine of slope.}$$

a = area of cross-section of pipe, conduit or open channel in square feet.

p = wetted perimeter of pipe, conduit or open channel in lineal feet.

r = hydraulic mean depth in feet = area of cross-section of pipe, conduit or open channel in square feet (*a*) divided by its wetted perimeter in

$$\text{lineal ft. } r = \frac{a}{p}$$

d = diameter of pipe or conduit.

n = the natural coefficient, the value of which depends on the nature and condition of the bed of the channel through which the water flows, or in other words, its degree of roughness.

The plan on which the tables are constructed will be briefly stated here and their use will be more fully explained further on.

Chezy's general form of formula for velocity is—

$$V = c\sqrt{rs} = c\sqrt{r} \times \sqrt{s}$$

therefore

$$Q = ac\sqrt{rs} = ac\sqrt{r} \times \sqrt{s}$$

The factors on the right hand side of the equations are tabulated, $c\sqrt{r}$ and $ac\sqrt{r}$ for diameters usually adopted in practice, and \sqrt{s} for 986 slopes.

Now to find the velocity, the diameter and slope being given. Look out and note down the number representing $c\sqrt{r}$ in its column and opposite the given diameter; also look out and note down the