OXY-ACETYLENE WELDING PRACTICE. A
PRACTICAL PRESENTATION OF THE MODERN
PROCESSES OF WELDING, CUTTING, AND
LEAD BURNING, WITH SPECIAL ATTENTION
TO WELDING TECHNIQUE FOR STEEL, CAST
IRON, ALUMINUM, COPPER, AND BRASS

Published @ 2017 Trieste Publishing Pty Ltd

ISBN 9780649445844

Oxy-Acetylene Welding Practice. A Practical Presentation of the Modern Processes of Welding, Cutting, and Lead Burning, with Special Attention to Welding Technique for Steel, Cast Iron, Aluminum, Copper, and Brass by Robert J. Kehl

Except for use in any review, the reproduction or utilisation of this work in whole or in part in any form by any electronic, mechanical or other means, now known or hereafter invented, including xerography, photocopying and recording, or in any information storage or retrieval system, is forbidden without the permission of the publisher, Trieste Publishing Pty Ltd, PO Box 1576 Collingwood, Victoria 3066 Australia.

All rights reserved.

Edited by Trieste Publishing Pty Ltd. Cover @ 2017

This book is sold subject to the condition that it shall not, by way of trade or otherwise, be lent, re-sold, hired out, or otherwise circulated without the publisher's prior consent in any form or binding or cover other than that in which it is published and without a similar condition including this condition being imposed on the subsequent purchaser.

www.triestepublishing.com

ROBERT J. KEHL

OXY-ACETYLENE WELDING PRACTICE. A
PRACTICAL PRESENTATION OF THE MODERN
PROCESSES OF WELDING, CUTTING, AND
LEAD BURNING, WITH SPECIAL ATTENTION
TO WELDING TECHNIQUE FOR STEEL, CAST
IRON, ALUMINUM, COPPER, AND BRASS



OXY-ACETYLENE WELDING PRACTICE

A PRACTICAL PRESENTATION OF THE MODERN PROCESSES OF WELDING, CUTTING, AND LEAD BURNING, WITH SPECIAL ATTENTION TO WELDING TECHNIQUE FOR STEEL, CAST IRON, ALUMINUM, COPPER, AND BRASS

ROBERT J. KEHL, M.F.

CONSULTING MECHANICAL ENGINEER, CHICAGO AMERICAN BOCKETY OF MECHANICAL ENGINEERS ASSOCIATE, AMERICAN INSTITUTE OF ELECTRICAL ENGINEERS

ILLUSTRATED

AMERICAN TECHNICAL SOCIETY CHICAGO 1918 COPTRIGHT, 1917, BY AMERICAN TECHNICAL SOCIETY

COPTRIGHTED IN GREAT BRITAIN
ALL RIGHTS RESERVED

INTRODUCTION

HIGH-TEMPERATURE flames, such as the oxy-hydrogen flame, were known for many years, but the oxy-acetylene flame was first used experimentally in 1901 by Fouché and Picard. The same experimenters also developed the first welding blowpipes, used industrially in 1903, and started the developments in oxy-acetylene welding which were destined to become so important in the modern manufacturing and repair fields. Cutting by means of oxygen was first made commercially possible in 1905 by Jottrand, who took out his basic patent in that year.

If Many difficulties were encountered in the early development, owing to imperfect knowledge of the character of the flame and of the technique of the method of application, but notwithstanding these difficulties, the oxy-acetylene welding and cutting processes have developed wonderfully, especially during the last ten years, during which time they have replaced old methods and have made possible operations which hitherto could not be accomplished. The discovery of liquid air greatly decreased the cost of oxygen, and the increase in the number of oxygen supply points throughout the country has removed the last obstacle to the rapid advance of the art. Everywhere manufacturers are very willing to supplant their old methods by the oxy-acetylene process.

Their rapid increase in the number of plants using the process has produced an active demand for skilled operators, a demand which unfortunately has been always much greater than the supply. However, now that the apparatus on the market has become standardized and our knowledge of good oxy-acetylene practice has reached a point where methods can be carefully outlined, the publishers of this little volume feel that an authoritative article on this subject will be appreciated by the many persons interested in the welding field. The material has been written for the welding operator as well as for the superintendent and manager. The examples have been taken from the automobile industry because in that field almost every phase or class of welding is covered, and while the instructions and data deal with automobile welding in particular, the repairman and manufacturer will find no difficulty in applying this information to their own particular needs. The publishers will be very glad to give special information to any reader, either through their own experts or through the help of the author himself,

OXY-ACRIVIENE WELDING IN AN AUTOMOBILE REPAIR SHOP

CONTENTS

WELDING PROCESSES	PAGE
Oxy-acetylene process	3
Advantages	
Gases	3
Generators	
Welding blowpipes	7
Oxy-acetylene flame	8
Expansion and contraction	
Preparation of work	
Welding rod	
Flux	
Strength of weld	4 (4 (4 (4)))
Oxy-acetylene cutting	
Electric processes	11
Methods	11
Spot-welder	
Arc welder	
TECHNIQUE OF OXY-ACETYLENE WELDING	
Simple welding job	14
Apparatus required	14
Preparing the metal	14
Connecting the apparatus	
Welding	15
Operation and care of welding apparatus	16
Necessity for care	16
Necessary welding apparatus	16
Welding blowpipe	
Regulators	
Hose	
Instructions for connecting apparatus	
How to light blowpipe	
How to shut off blowpipe	
Back-firing	
Character of flame	
Position of blowpipe	
Position of welding rod	
Haste fatal to good welding	
How to weld up a hole	
Overhead and vertical welding	
Beginning a long weld.	
Defects in welds	

CONTENTS

	AGE
Welding different metals	
Properties of metals	34
Expansion and contraction	
Handling simple case of expansion and contraction	
Handling complex case of expansion and contraction	39
Pre-heating	40
Steel welding	43
Cast-iron welding	
Malleable-iron welding	67
Aluminum welding	68
Copper welding	
Brass and bronze welding	74
MISCELLANEOUS OXY-ACETYLENE PROCESSES	
Cutting	76
Principle of cutting with oxygen	
Cutting blowpipe	
Regulators	
Care of apparatus	
Instructions for connecting apparatus	
How to light blowpipe	
To shut off blowpipe.	
Back-firing	
Notes on cutting	
Lead burning	
Different methods	- 752
Lead-burning apparatus.	1000
Operation of lead-burning apparatus.	
Lead-burning process	
Carbon removing by use of oxygen	
Old process of removing carbon	
Carbon-removing apparatus.	
Burning out carbon.	
	· Ot
EXAMPLES OF AUTOMOBILE REPAIR	
Pressed-steel parts	
Frames	
Bodies and fenders	
Springs	
Shafts and axles	93
Axle housings	94
Manifolda	94
Engine cylinders	
Crankeases and transmission cases	97
COSTS	
Measuring oxygen consumption	99
Measuring acetylene consumption	102

* x o i

H